

Sized for Ten Tec TP41 Enclosure

The bottom edge of the template matches the bottom edge of the board, plus 1/4" for 1/4" spacers om the rear mounting bolts. Align the label from the top of the enclosure front panel.

Power Jack Hole Location
Template. Power jack access hole is on rear panel.

Place this corner of template at Top RH Corner of rear panel before marking hole Location

3/8 Hole
Use Mouser
#1710-2531
Power Plug

Align side of template with side of panel before marking hole location